

Slip Proof NZ Tape Fitting Instruction

- Clean surface thoroughly with either methylated spirits and rags or detergent and water, ensuring no grease or grime is on surface. Allow to dry completely
- Cut tapes to desired length and round off corners
- Lay tapes down in final location (do not remove backing yet) and mark around edges with chalk or builders' pencil
- For rough surfaces prime with Nuplex Neoprime inside marked area ensuring to roll up to edges (use medium nap roller 75mm for 100mm tape)
- Allow to dry for 1 to 10 minutes depending on temperature
- Once primer is dry peel off tape backing and lay down tapes
- Walk over entire tape surface to ensure complete adhesion

Please note common sense should be used in relation to installation of tape.

Rough concrete may require 2 coats of Neoprime.

High humidity days or wet conditions should be avoided to ensure tapes do not lift.

Because the application of these products are out of our control, Slip Proof NZ Ltd cannot and will not except any liability for any injury or damage caused by using these products, or longevity of product.