

SLIPPROOFNZ

ANTI-SLIP SAFETY SOLUTIONS

COMMERCIAL | INDUSTRIAL | RESIDENTIAL

FLOORING SUPPLIES PRODUCT, SUPPLIED TO YOU BY SLIP PROOF NZ ANTI-SLIP SYSTEM APPLICATION PROCEDURE FOR TERRAZZO, CONCRETE, MARBLE & STONE

Thank you for choosing our Slip Proof NZ anti-slip system. Please read this procedure sheet before commencing application.

Check the contents of this box. Should there be any shortage or damage please call us on 07-5422240.

This Slip Proof anti-slip system pack contains FIVE products.

Product No.1 (pink liquid) Product No.2 (green liquid) Product No.3 (blue liquid) & Product TC (orange liquid) and a commercial Maintenance Cleaner (also blue liquid). The four (no.1, no.2, no.3 and TC) products used together will make your slippery floor anti-slip safe.

BEFORE YOU START:

Remove all items from the area to be treated and sweep up all loose debris.

Lay towelling or protection sheet down beside working area to stand equipment on.

Make sure you have everything ready before you start; soft broom, squeegee, watering can, mop & bucket (or hose) with plenty of clean cold water.

During application avoid splashing or walking products onto other floor surfaces as staining may occur.

Never allow the products to dry out. Do not apply to hot surfaces.

SHOWERS: Clean thoroughly to remove any build up of soaps, body fats etc before commencing application

DIRECTIONS FOR APPLICATION:

USE ALL THE LIQUID PROVIDED IN EACH BOTTLE

- 1) Wet the area to be treated by using a wet mop or hose. Pour out product No.1 over the surface to be treated. Using a soft broom spread the solution over the floor surface to completely wet the floor.
- 2) Whilst product No.1 is wet, immediately and carefully pour out product TC over the surface and very quickly brush the liquid over product No.1 avoiding splashing walls or equipment.
- 3) Leave for 5 minutes then rinse products from floor with plenty of clean water.
- 4) Brush excess liquids down drain waste outlet or mop up leaving the floor damp/wet.
- 5) Ensure area is still wet with water only. Pour out product No.2 over surface to be treated and brush liquid over the damp/wet surface. Brush this product well into the surface.

This product will now start to create the anti-slip effect. The leave on time to produce the required anti-slip effect varies from surface to surface. Typically, between 3 – 10 minutes is all that's required. Do not let the area dry out during treatment, spray with a little water if it appears to be drying. **DO NOT LEAVE PRODUCTS ON FOR LONGER THEN REQUIRED** as over treatment may cause difficulties in cleaning the floor after treatment. To judge this, push your foot (with rubber soled shoe) with weight into the solutions on the floor. As soon as you feel your foot gripping, the anti-slip is completed and step 6 should be done as quickly as possible.

6) Pour out product No.3 over the top of product No.2 and brush liquid over area.

7) Immediately rinse the floor with plenty of clean water. Brush as much of the liquid down the waste drain outlet.

8) Repeat step 7.

9) Mop over floor and skirtings with clean water once or twice and leave to dry.

Depending on the colour and surface a slight dullness or a 'Bloom' maybe visible after the treatment has dried. This is quite normal and will disappear with on-going cleaning.

A specially formulated cleaning product is provided in the box. Using this cleaner to clean your floor will keep your floor clean & anti-slip safe. For further supplies please call, email or order on our website.

Because the application of these products are out of our control, Slip Proof NZ Ltd cannot and will not accept any liability for any injury or damage caused by using these products.