



Slip Proof NZ MFRP Nosing fitting recommendations for wooden, masonry and concrete floors.

Pre Clean:

Before fitting MFRP nosing's, ensure to pre clean the underside with Soudal Surface Activator (available to purchase through Slip Proof) or acetone. This removes any contaminants and promotes a good adhesion key for the adhesive.

Fasteners:

Stainless steel screw and plug method 8-gauge screws, concrete plugs.
Gorilla Fix All Turbo adhesive

Fitting instructions for concrete surface:

1. Predrill holes evenly along middle of top of nosing (maximum 500mm centres): including one approx. 10cm from each end
2. Ensure surface is clean, dry, and free of any foreign matter
3. Mark through the holes using a permanent marker pen on to concrete surface
4. Drill holes in surface to 50mm depth
5. Clean drillings off surface and insert plugs
6. Turn over each deck tread or nosing and apply a zig zag line of Gorilla Fix All Turbo along the underside
7. Turn the nosing over so the antislip side is uppermost and locate it back in the fitted position marks. Screw down firmly in place
8. Walk over the entire length of the deck tread or nosing to ensure mastic makes full contact with both surfaces
9. Clean up any residue mastic with acetone

Fitting instructions for wooden surfaces:

As above, with the exception of using plugs these; will not be needed.

Fitting instructions for tile and waterproof stairs:

Use extra adhesive, use of bricks or similar weights can be used on top of the nosing's till cured.

Disclaimer:

- Please note, these are recommendations only and should be used as a guide only.
- Slip Proof NZ MFRP nosings adhere to multiple industry standard adhesives. It is up to the installer to determine the suitability of any products.
- Slip Proof NZ will not accept any liability for failures due to installation error or those that aren't a Slip Proof NZ Ltd MFRP stair nosing direct fault.