



Aluminium Nosing fitting recommendations for following profiles:

SKU: AL-CAR-77, A4-CAR-76, A1-CAR-59, AAI-57

Please note, the following is a recommendation only and should be used as a guide. As every stair surface and substrate differ, common sense should prevail when fitting. Gorilla Fix All Turbo adhesive should be ordered with purchase.

Fitting to wooden, concrete, tile and waterproof stairs:

- Clean stair thoroughly from any grime, oil, etc.
- Clean underside of stair nosing with Surface Activator (available at Slip Proof) or acetone
- Place zigzag pattern of adhesive (Gorilla Fix All TURBO available at Slip Proof) on underside of nosing and stick down ensuring adhesion along the entire length.
- Clean up any excess adhesive with acetone and a plastic scraper.

Please note if stair surface is uneven the use of weights, i.e bricks on top of nosing can be used until adhesive cures

DO NOT DRILL through the carborundum section of the stair nosing. Should screws be required, these can be drilled through the front riser section of the nosing.

Disclaimer

- Please note, these are recommendations only and should be used as a guide only.
- Slip Proof NZ aluminium nosing's adhere to multiple industry standard adhesives. It is up to the installer to determine the suitability of any products.
- Slip Proof NZ will not accept any liability for failures due to installation error or those that aren't a Slip Proof NZ Ltd aluminium stair nosing direct fault.